



STEEDA

2020 Explorer Rear Toe Link

Instructions for 555-4118

NOTE: The vehicle will require an alignment after installation.

Installation

1. Lift the rear of the vehicle and support with jack stands.
2. Unbolt and remove the factory rear toe links.
3. Set the Steeda adjustable rear toe link to the same length as the factory tighten jam nuts.
4. Install the Steeda adjustable rear toe links by squeezing the polyurethane bushing from both side. Shown figure 1.

NOTE: Use the grease provided on the outer face of the bushings for easier install.

5. Lower the vehicle.
6. Using the supplied 16mm class 10.9 bolts and locking nuts, install lockout plates on both sides (2 per side) mounted all the way to the inside of the sub frame. See figure 3.

NOTE: The bolt must be torqued at 160 lb-ft on the ground.

7. Have vehicle professionally aligned to avoid abnormal tire wear.

